



WARNING!

TYPHOON WX SERIES - WATER PUMP MOTOR



READ
BEFORE
USE


This manual contains specific cautionary statements related to worker safety. To protect yourself and others, read this manual thoroughly and follow as directed before use. Not all hazards of fume & dust control are listed in this manual, and no hazards related to welding, cutting, grinding, painting, deburring or other applications are listed. Consult a qualified safety professional.

1. Safety


The drive motor on the filtration system must be run **CLOCKWISE** only.

SEVERE DAMAGE will occur to the water pump if the water pump motor is wired incorrectly, even one time.


2. Overview of the filtration system




2.1 Remove the yellow shaft cover




2.2 Verify the motor side shaft coupler is disconnected



2.3 Wire & power on the pump motor to verify the rotation is correct



2.4 Verify clockwise direction and re-attach shaft coupler



Once the water pump motor is verified to be running in a clockwise motion (same as the arrow indicator), the shaft coupler can be re-attached, and the set screw fastened to secure it in place.



2.5 The last step is to refasten the shaft cover

